


DATED IM-12-15-70

ROCKWELL/DELTA 20" WOOD/NON-FERROUS CUTTING BAND SAW

Series # 28-3x0 Serial # 1512269

No. 28-340 Band Saw

Shown with Accessory 25-857 Lamp Attachment, 28-701 Blade Welder and Flash Grinder, 28-005 Blade Shear, and Electri-



- READ the instruction manual before operating your machine.
- 2. IF YOU ARE NOT thoroughly familiar with the operation of Band Saws and Scroll Saws, obtain advice from your supervisor, instructor or other qualified person.
- 3. REMOVE tie, rings, watch and other jewelry, and roll up sleeves.
- 4. ALWAYS wear safety glasses or a face shield.
- 5 MAKE SURE wiring codes and recommended electrical connection instructions are followed and that machine is properly grounded.
- **6** MAKE all adjustments with the power off.
- CHECK all adjustments on the scroll saw by rotating the motor by hand before turning power on.
- 8. LOWER the hold down on the scroll saw so that it presses lightly on the material being cut.
- **9.** ADJUST the upper guide on the band saw about 1/8" above the material being cut.

- 10. MAKE SURE that blade tension and blace tracking are properly adjusted on the band saw.
- 11. STOP the machine before removing scrap pieces from the table.
- **12.** ALWAYS keep hands and fingers away from blade.
- **13.** CHECK for proper blade size and type.
- 14. DO NOT attempt to saw stock that does not have a flat surface, unless a suitable support is used.
- 15. HOLD material firmly and feed into blade at a moderate speed.
- TURN OFF the machine if the material is to be backed out of an uncompleted cut.
- 17. MAKE "release" cuts before cutting long curves.
- 18. DISCONNECT machine from power source when making repairs.
- 19. SHUT OFF power and do not leave machine until it has come to a complete stop.
- 20. BEFORE LEAVING the machine, make sure the work area is clean.